

Clarinet Parts

Part #	Description	Part #	Description	Part #	Description	Part #	Description	Part #	Description
1	Bell	11	B-F# key	21	Bb and C trill pivot rod	31	F# ring key	41	F#-C# lever pivot rod
2	Lower joint	12	Low F-C key	22	Thumb ring key	32	A-D upper bridge key	42	E-B lever pivot rod
3	Upper joint	13	Ab-Eb key	23	Thumb ring key pivot rod	33	Ring and bridge key pivot rod	43	Flat spring
4	Barrel	14	Low F and Ab pivot rod	24	Eb-Bb auxiliary key	34	Register key	44	Flat spring retainer screw
5	Mouthpiece	15	Eb-Bb trill key	25	Auxiliary key pivot rod	35	Register key pivot rod	45	Pivot screw
6	Ligature	16	F# trill key	26	C#-G# key	36	A key	46	Low F-C adjustment screw
7	Ligature screw	17	Bb trill key	27	C#- G# pivot rod	37	A key pivot rod	47	Thumb rest screw (not shown)
8	Low E-B key	18	C trill key	28	Top G# key	38	F-C lever	48	Thumb rest (not shown)
9	Lower bridge key	19	Eb trill pivot rod	29	G# pivot rod	39	E-B lever		
10	F#-C# key	20	F# trill pivot rod	30	G# adjustment screw	40	F#-C# lever		